

# Installation Guide

The doorset installation should be in accordance with BS EN 1634-1 & BS 476 Part 22 and manufacturers guidelines.

- During the application, the temperature of the can and room should be between +5 °C and +30 °C
- Frame / wall surface must be free from dust and grease
- Moistening the surfaces before and after the application will ensure faster curing and increase the bonding strength
- Tested with gaps between 7mm and 30mm
- Where fixing points occur pack securely using **Blue60™** fire rated packers (A)
- Screw on the applicator gun / nozzle and shake can
- Hold the can upside down and activate the foam by pressing the valve
- IMPORTANT - The junction between the door frame and the substrate should be fully filled with **Blue60™** fire rated foam (B)
- Architraves can then be fitted over un-cured foam or alternatively foam can be allowed to cure and then be removed mechanically

